
GB AMW 510

QUICK REFERENCE GUIDE

CONTROL PANEL



CHOOSING MICROWAVE POWER

MICROWAVES ONLY

Level To be used for:

JET / 900 W Reheating of beverages, water, clear soups, coffee, tea or other food with a high

water content. If the food contains egg or cream choose a lower power.

750 W Cooking of vegetables, fish, meat etc. 650 W Cooking dishes, not possible to stir.

500 W More careful cooking e.g. high protein sauces, cheese and egg dishes and to

finish cooking casseroles.

350 W Simmering stews, melting butter.

160 W ★ Defrosting.

90 W Softening butter, cheese and ice cream.

0 W Setting the standing time.

MICROWAVES & GRILL

Level	To be used for:
90 - 160 W	Large cuts of mea
160 - 350 W	Fish
350 - 500 W	Poultry
500 - 650 W	Gratin's

MANUAL DEFROSTING

This function is used for defrosting food not included in the Jet defrost function.

Follow the procedure for "How to cook and reheat with microwaves" and choose 160 W when defrosting manually.

JET START FUNCTION

This function is used for quick reheating of food with a high water content such as; clear soups, coffe or tea.

Press to automatically start with full microwave power level and the cooking time set to 30 seconds. Each additional press increases the time with $\frac{1}{2}$ min. You may also alter the time by turning the Adjust knob to increase or decrease the time.

This button also works as a normal start button after setting a function.





AMW 510

QUICK REFERENCE GUIDE

[AUTO] **AUTO FUNCTIONS**

QUICK GUIDE

- 1. **Turn** the multifunction knob to the Auto position.
- 2. **Press** the Auto button to select the desired auto function.
- 3. **Turn** the +/- knob to choose desired food class.
- 4. **Press** the Select button (default weight is displayed).
- 5. **Turn** the +/- knob to set the weight of the food.
- Press the Start button.

Midway thru the process, the oven may STOP and prompt you to "TURN or STIR FOOD":

- Don't use the stop button!
- Just open the door and turn the food.
- Close, and restart with the Jet Start button.

Automatic but less perfect results:

If you do not turn the food when the oven prompts you to do so, the oven will AUTOMATICALLY RESTART after 2 minutes. The oven then completes the process. The time will be longer in this case and the result will be less perfect, than it would have been if you had turned the food when prompted to do so.

AUTO * JET DEFROST

Use this function for defrosting ONLY. Jet Defrost can only be used for very fast defrosting of frozen food belonging to the categories listed here. Use manual defrost for other food or weights not listed.



1 MEAT (100 g - 2 Kg)



2 POULTRY (100 a - 3 Ka)





3 FISH (100 g - 2 Kg)

to do so.



WEIGHT of the food selected.

PLEASE NOTICE

To achieve perfect results it is NECESSARY

— Input, with the max, possible precision, the

— Turn the food when the oven prompts you

4 VEGETABLES (100 a - 2 Kg)



5 BREAD (100 a - 2 Ka)

AUTO " **AUTO REHEAT**

Use this function when reheating readymade food or milk. Auto Reheat can be used for food belonging to the categories listed here.

PLEASE NOTICE

During the heating process the oven may stop and prompt you to "STIR" food.



1 DINNER PLATE (250 a - 650 a)



2 SOUP (200 g - 800 g)



3 FROZEN PORTION (250 g - 650 g)



4 MILK

5 CASSEROLE (100 g - 500 g) (200 g - 800 g)

NOTE: Never operate the oven empty when using microwaves



AUTO IIII

Use this function for cooking ONLY. Auto Cook can only be used for food belonging to

the categories listed here. Use "Cook & Reheat with microwaves" for other food or weights not listed.



1 BAKED POTATOES (200 g - 1 Kg)



2 FRESH **VEGETABLES** (200 g - 800 g)



AUTO COOK

3 FROZEN **VEGETABLES** (200 g - 800 g)



to "TURN or STIR" food.

PLEASE NOTICE

During the cooking process the oven may

stop (depending on program) and prompt you

4 CANNED **VEGETABLES** (150 g - 600 g)

PLEASE NOTICE

Auto Crisp is used only for frozen ready



5 POPCORN (90 g - 100 g)

AUTO 🔼

Use this function to quickly reheat your food from frozen to serving temperature.



1 FRENCH FRIES (200 g - 600 g)

-

Sausages

Pommes Duchesse

Gratinated fruit

 Potato gratin • Fish gratin

Lasagne

Chicken pieces

Stuffed vegetables

Grill spit



2 PIZZA, thin crust

Use this function when cooking:

网 GRILL & MICROWAVES

Use this function when cooking:

• Cheese toast & Hot sandwich

GRILL



(200 g - 500 g)



AUTO CRISP

3 PAN PIZZA (300 g - 800 g)



made food and fish fingers.

WINGS



4 CHICKEN (200 g - 600 g)

5 FISH **FINGERS**

(200 g - 600 g)

TECHNICAL SPECIFICATION

Supply voltage	230-240 V/50 Hz
Rated Power Input	2800 W
Fuse	16 A (UK 13 A)
MW output power	900 W
Grill	1600 W
	H x W x D
Outer dimensions:	455 x 595 x 510
Oven compartment:	210 x 450 x 420

